




PARTS BOOK


XTREET II
250 CC




www.umglobal.com

E01 = 进气和排气系统 / AIR INLET EXHAUST SYSTEM / TREN DE VALVULAS				
ITEM	UM Part #	Description	Spanish	Qty
1	E01040065	LOWER ROCKER ARM	BRAZO IMPULSADOR INFERIOR	2
2	E01040064	SHAFT, LOWER ROCKER ARM A	EJE INFERIOR DE BALANCIN A	1
3	E01050028	VALVE COTTER	SEGURO, VÁLVULA	4
4	E01050027	RETAINER,V ALVE SPRING	RETENEDOR DEL RESORTE DE VÁLVULA	2
5	E01040069	VALVE INNER & OUTER SPRING	RESORTE INTERIOR, VÁLVULA	2
	E01040069	VALVE INNER & OUTER SPRING	RESORTE EXTERIOR, VÁLVULA	2
7	E01040010	RETAINER, VALVE INNER SPRING	ASIENTO DEL RESORTE INTERIOR, VÁLVULA	2
8	E01040001	RETAINER, VALVE OUTER SPRING	ASIENTO DEL RESORTE EXTERIOR, VÁLVULA	2
9	E01020001	VALVE STEM SEAL ASSY	SELLO DE ACEITE, VÁSTAGO VÁLVULA	2
10	E01050025	INLET VALVE	VÁLVULA INT.	1
11	E01050026	EXHAUST VALVE	VÁLVULA EXT.	1
12	E01010012	CAMSHAFT,ASSY	BALANCIN	1
13	E01010013	TIMING DRIVEN SPROCKET	ENGRANAJE DE TIEMPO	1
14	E01060040	BOLT M6×12	TORNILLO M6×12	2
15	E01040062	POSITION PLATE,ROCKER SHAFT	POSICIONADOR DE BALANCIN	1
16	E01060039	BOLT M6×16	TORNILLO M6×16	1
17	E01040067	GUIDE COMP.,CAM CHAIN	GUIA TENSORA DE CADENA	1
18	E01040063	CHAIN,CAM	CADENA DE CAMARA	1
19	E01040066	TENSIONER,CAM	GUIA DE CADENA	1
20	E01060018	WASHER 8.5×1.5×14	ARANDELA 8.5×1.5×14	1
21	E01040070	BOLT	TORNILLO	1
22	E01040068	TENSION	IMPULSOR DE TENSOR DE CADENA	1
23	E01060038	BOLT M6×16	TORNILLO M6×16	2


		E02 = 化油器和发动机 / CARBURETOR AND ENGINE / CARBURADOR Y MOTOR				
		ITEM	UM Part #	Description	Spanish	Qty
		1	E02030018	250CC ENGINE ASSY	250CC MOTOR COMPLETO	1
		2	E02010019	CARBURETOR	CARBURADOR	1



E03 = 离合器 / CLUTCH / EMBRAGUE				
ITEM	UM Part #	Description	Spanish	Qty
1	E03020023	CLUTCH ASSEMBLY	PRENSA DE EMBRAGUE COMPLETA	1
2	E03060033	ROD,CLUTCH PUSH	IMPULSOR DE CLUTCH	1
3	E03050001	BEARING (16003)	RODAMIENTO16003	1
4	E03060036	BOLT M6×20	TORNILLO M6 X 20	6
5	E03010001	END COVER, CLUTCH	CUBIERTA FINAL DE CLUTCH	1
6	E03060023	SPRING, CLUTCH	RESORTE	6
7	E03060006	CIRCLIP 20, CLUTCH	CLIP 20	1
8	E03020002	CENTRAL SLEEVE., CLUTCH	CUBO DE TRASMISION	1
9	E03030015	FRICTION PLATE, DRIVE, CLUTCH	PLATO DE CLUTCH A	6
10	E03030014	FRICTION PLATE, DRIVEN, CLUTCH	PLATO DE CORREA	5
11	E03030001	PRESSURE PLATE, CLUTCH	PLATO DE PRESION	1
12	E03060032	SPLINE WASHER, CLUTCH	ARANDELA	1
13	E03020001	OUTER CASE ASSEMBLY, CLUTCH	CONJ CAMPANA DE CLUTCH	1
14	E03060035	LOCATING SLEEVE, MAINSHAFT	ANILLO DE RETENCIÓN	1
15	E03060034	SEPARATING AXLE SLEEVE	SEPARADOR DEL IMPULSOR DE CLUTCH	1




E04 = 曲轴箱 / CRANKCASE ASSEMBLY / CARCAZAS DE MOTOR (CARTER)				
ITEM	UM Part #	Description	Spanish	Qty
1	E04010024	ASSEMBLY, RIGHT CRANKCASE SILV	CONJ CARCAZA DE MOTOR LADO DERECHO	1
2	E04060075	STEEL BRACKET, CLUTCH	SOPORTE DE GUAYA DE CLUTCH	1
3	E04060081	BOLT M6×55	TORNILLO M6 × 55	1
4	E04060078	CB200-2# STUD B (229mm)	CB200-2# TORNILLO CILINDRO B (229mm)	2
5	E04060077	CB200 STUD B (229mm)	CB200 TORNILLO CILINDRO B (229mm)	4
6	E04060073	IN TUBE 2#	MANGUERA DE DESHAOGO	1
7	E04060048	HOSE CLAMP	SEGURO DE MANGUERA	3
8	E04060074	OIL SEPARATOR	SEPARADOR DE ACEITE	1
9	E04060072	IN TUBE 3#	MANGUERA	1
10	E04060013	DOWEL PIN 10×14	PASADOR 10×14	4
11	E04030001	NEEDLE BEARING (NK15×23×12)	CANASTILLA EJE SALIDA (NK15×23×12)	1
12	E04030014	BEARING (6006)	RODAMIENTO (6006)	1
13	E04030016	NEEDLE BEARING (HK21×28×10)	CANASTILLA EJE SALIDA (HK21×28×10)	1
14	E04020028	GASKET, CRANKCASE	EMPAQUETADURA DE CARTER	1
15	E04010023	ASSEMBLY, LEFT CRANKCASE, SILV	CONJ CARCAZA DE MOTOR LADO IZQ.	1
16	E04030015	BEARING (TM6202Z)	RODAMIENTO (TM6202Z)	1
17	E04060076	STUD A (240mm)	TORNILLO CILINDRO A (240mm)	2
18	E04060056	RETAINER, CABLE	GUÍA	1
19	E04060055	BOLT M6×12	TORNILLO M6×12	1
20	E04020007	OIL SEAL 20×34×7	SELLO DE ACEITE 20×34×7	1
21	E04020002	OIL SEAL 14×28×7	SELLO DE ACEITE 14×28×7	1
22	E04050003	ASSEMBLY, OIL FILTER SCREEN	FILTRO COLADOR DE ACEITE	1
23	E04050002	SPRING, OIL FILTER SCREEN	RESORTE DE FILTRO / COLADOR DE ACEITE	1
24	E04050020	O-RING 35×3	O-RING 35×3	1
25	E04060071	CAP, TAPPET ADJUSTING HOLE	TORNILLO DE DRENAJE	1
26	E04060030	WASHER 12.4×2×20 (ALUMINIUM)	ARANDELA 12.4×2×20	1
27	E04060079	OIL DRAIN PLUG M12×1.5	TAPÓN DE DRENAJE M12×1.5	1
28	E04060080	BOLT M6×50	TORNILLO M6×50	11



E05 = 曲轴 & 活塞 / CRANKSHAFT & PISTON / CIGÜEÑAL, PISTON Y ANILLOS				
ITEM	UM Part #	Description	Spanish	Qty
1	E05010123	ASSEMBLY, PISTON RING	JGO. ANILLOS STD.	1
2	E05010121	PISTON	PISTON	1
3	E05010124	CIRCLIP, PISTON PIN	ANILLO DE RETENCIÓN PISTÓN	2
4	E05010122	PISTON PIN	PISTON PIN	1
5	E05020008	ASSEMBLY, CONNECTING ROD CRANK	CONJ CIGÜEÑAL	1
6	E05030001	SEMICIRCULAR KEY 25×14×4	LLAVE SEMI-CIRCULAR 25 × 14 × 4	1
7	E05010125	SEMICIRCULAR KEY 19×11.4×4	LLAVE SEMI-CIRCULAR 19×11.4×4	1
8	E05030029	BEARING (TM-SC06B42)	RODAMIENTO (TM-SC06B42)	1
9	E05030026	DRIVING GEAR, BALANCE	EJE DE DIRECCION DE ENGRANAJE	1
10	E11040023	DRIVE GEAR	ENGRANAJE DE ARBOL DE LEVA	1
11	E05030010	BEARING (6203)	RODAMIENTO (6203)	1
12	E05030031	BALANCE SHAFT	EJE DE BALANCE	1
13	E05010126	SEMICIRCULAR KEY 12.5×4×4	LLAVE SEMI-CIRCULAR 12.5×4×4	1
14	E05030005	BEARING (6303)	RODAMIENTO 6303	1
15	E05030027	DRIVE GEAR SET, BALANCE SHAFT	SET DE ENGRANAJES DE BALANCEADOR	1
16	E05030030	THRUST WASHER 16.2×2.7×22.5	ESPACIADOR 16.2×2.7×22.5	1
17	E05030028	LOCK NUT M16×1-6H (LEFT)	TORNILLO DE CIERRE IZQUIERDO M16×1-6H	1




E06 = 汽缸体 / CYLINDER BLOCK / CILINDRO DE MOTOR				
ITEM	UM Part #	Description	Spanish	Qty
1	E06010015	CYLINDER BLOCK COMP, SILVER	CONJ BLOQUE MOTOR	1
2	E06030001	DOWEL PIN 10×20	PASADOR 10×20	2
3	E06020021	GASKET ASSY,CYLINDER HEAD	EMPAQUETADURA DE TAPA DE VALVULA	1
4	E06020020	GASKET,CYLINDER BLOCK	EMPAQUETADURA DE CILINDRO	1




E07 = 汽缸头和盖 / CYLINDER HEAD & COVERS / CULATA Y CUBIERTAS				
ITEM	UM Part #	Description	Spanish	Qty
1	E07010045	CYLINDER HEAD ASSY SILVER	CONJ CAMARIN	1
2	E07010046	CAP ASSEMBLY, TAPPET ADJUSTING HOLE	TAPON DEL AJUSTE DE ELEVADORES	2
3	E04050020	O-RING 35×3	O-RING 35×3	2
4	E07050022	BOLT M6×35	TORNILLO M6×35	4
5	E07050021	NUT M8	TUERCAM8	4
6	E01060007	WASHER 8.5×2×18	ARANDELA 8.5×2×18	4
7	E07050016	PLASTIC PLUG	TAPON PLASTICO	1
8	E07020001	SPARK PLUG (D8TC)	BUJÍA DE ENCENDIDO(D8TC)	1
9	E07050020	BOLT M8×36	ESPARRAGOS M8×36	2
10	E09050009	DOWEL PIN 8×14×6.3	PASADOR 8×14×6.3	2
11	E07030002	O-RING 33.5×3	O-RING 33.5 × 3	1
12	E07050017	PIPE COMP,INTAKE (JQ-41)	GOMA MANIFOLD (JQ-41)	1
13	E07040010	BOLT M6×20	TORNILLO M6 × 30	2
14	E07040009	NUT M6	TUERCA M6	4
15	E07050019	GASKET, L.CYLINDER LEFT COVER	EMPAQUE CUBIERTA LATERAL DE CABEZA	1
16	E07050018	O-RING 75×2.65	O-RING 75×2.65	1
17	E07010044	COVER, L.CYLINDER HEAD SIDE	CUBIERTA IZQUIERDA DE CABEZA DE CILINDRO	1
18	E07040058	BOLT M6×20	TORNILLO M6×20	2
19	E07040059	BOLT M6×125	TORNILLO M6×125	1
20	E07040057	WASHER 6.2×2×13	ARANDELA 6.2×2×13	1



E08 = 齿轮 / GEAR SHIFTING / TAMBOR SELECTOR				
ITEM	UM Part #	Description	Spanish	Qty
1	E08010027	GEARSHIFT DRUM	SELECTOR DE CAMBIO	1
2	E08010003	SHAFT, FORK SPREADER	EJE GUIA DE HORQUILLA	1
3	E08040026	PIN 4×10	PIN 4×10	1
4	E08010007	STOPPING PLATE	PLATO DE ENGRANAJE PRINCIPAL	1
5	E08040025	SPRING WASHER φ6	ARANDELA DE PRESIÓN φ6	1
6	E08040024	BOLT M6×25	TORNILLO M6×25	1
7	E08010004	RIGHT FORK SPREADER,COUNTERSHAFT	ENGRANAJE PRINCIPAL DE HORQUILLA DER.	1
8	E08010005	FORK SPREADER, MAINSHAFT	ENGRANAJE CENTRAL DE HORQUILLA	1
9	E08010006	LEFT FORK SPREADER, COUNTERSHAFT	ENGRANAJE PRINCIPAL HORQUILLA IZQ.	1
10	E08010028	ASSEMBLY, GEARSHIFT LEVER	EJE DE CAMBIOS COMPLETO	1
11	E08030007	CABLE ASSEMBLY, GEAR INDICATION	INTERRUPTOR IINDICADOR DE CAMBIOS	1
12	E08040027	BOLT M6×20	TORNILLO M6×20	1
13	E08030006	CONTACT, CEARINDICATION	CONTACTO DE INDICADOR DE CAMBIOS	1
14	E08040028	BOLT M6×20	TORNILLO M6×20	1
15	E08040023	SPRING, LOCATING PLATE	RESORTE	1
16	E08040002	ASSEMBLY, LOCATING PLATE	SWITCH DE ROTOR NEUTRAL	1



E09 = 右曲轴箱 / RIGHT CRANKCASE COVER / CUBIERTA DERECHA DE MOTOR				
ITEM	UM Part #	Description	Spanish	Qty
1	E09010027	ASSEMBLY, RIGHT CRANKCASE COVE	TAPA DE MOTOR	1
2	E09020006	CONTROLLING ARM ASSEMBLY,CLUT	PALANCA DE CLUTCH	1
3	E09050031	SPRING, CONTROLLING ARM, CLUTCH	RESORTE DE PALANCA DE CLUTCH	1
4	E09050034	PIN 3×12	PIN 3×12	1
5	E09050032	O-RING 8.7×1.9	O-RING 8.7×1.9	1
6	E09020005	PLASTIC OIL BOLT	BALLONETA MEDIDORA DE ACEITE	1
7	E12030007	OIL SEAL 18×3	SELLO DE ACEITE 18×3	1
8	E12030002	OIL SEAL 16×28×7	SELLO DE ACEITE 16×28×7	1
9	E12050002	WINDOW, OIL LEVEL	SENSOR DE NIVEL DE ACEITE	1
10	E12030001	GASKET, RIGHT CRAMKCASE COVER	EMPAQUETADURA DE TAPA DE MOTOR	1
11	E09050033	SCREW M6×12	TORNILLO M6×12	1
12	E09050036	BOLT M6×45	TORNILLO M6×45	1
13	E09050035	BOLT M6×40	TORNILLO M6×40	11














E10 = 磁电机 / MAGNETO / GENERADOR				
ITEM	UM Part #	Description	Spanish	Qty
1	E10010011	STATOR ASSEMBLY, MAGNETO	ESTATOR	1
2	E10030011	SCREW M5×16	TORNILLO M5×16	2
3	E10030012	BOLT M5×25	TORNILLO M5×25	3
4	E10020012	ROTOR ASSEMBLY, MAGNETO	ROTATOR	1
5	E10030009	BOLT M10×36	TORNILLO PIVOTE M10×36	1
6	E10030010	BOLT M8×18	TORNILLO PIVOTE M8×18	3


Exploded view diagram of the oil pump and filter assembly. The diagram shows 12 numbered components:

- 1: Oil filter assembly
- 2: Nut
- 3: Dish washer
- 4: Gasket
- 5: Drive sprocket
- 6: Chain
- 7: Nut M6
- 8: Drive sprocket assembly
- 9: Bolt M6x32
- 10: Oil pump
- 11: Cover
- 12: Bolt M6x12

E11 = 油泵 & 汽油过滤器 / OIL PUMP&OIL FILTER COMP / BOMBA DE ACEITE Y FILTROS				
ITEM	UM Part #	Description	Spanish	Qty
1	E11020001	ASSEMBLY, OIL FILTER	FILTRO DE ACEITE	1
2	E03050011	NUT, OIL FILTER	PIÑON BOMBA DE ACEITE	1
3	E11040003	DISH WASHER, CLUTCH 16.5×2×27	ARANDELA CLUTCH 16.5×2×27	1
4	E11030001	GASKET, OIL FILTER COVER	EMPAQUETADURA	1
5	E03050012	DRIVE SPROCKET, OIL PUMP	SPROCKET BOMBA DE ACEITE	1
6	E11010006	CHAIN, OIL PUMP	CADENA DE BOMBA DE ACEITE	1
7	E11040024	NUT M6	TUERCA M6	1
8	E11040022	DRIVE SPROCKET ASSEMBLY, OIL PUMP	PIÑON DE DIRECCION BOMBA DE ACEITE	1
9	E11040025	BOLT M6×32	TORNILLO M6 X 32	2
10	E11010001	OIL PUMP	CUBIERTA BOMBA DE ACEITE	1
11	E11010007	COVER, SPROCKET WHEEL, OIL PUMP	PIÑON DE BOMBA DE ACEITE	1
12	E04060055	BOLT M6×12	TORNILLO M6×12	2



E12 = 左箱体 / LIFE CRANKCASE COVER / CUBIERTA IZQUIERDA DE MOTOR				
ITEM	UM Part #	Description	Spanish	Qty
1	E12010026	FRONT COVER, LEFT CRANKCASE, SI	CUBIERTA DE TAPA DE MOTOR	1
2	E12010028	DECORATE COVER, FRONT COVER	CUBIERTA DE DECORACION	1
3	E12030021	O-RING 27.4×2.65	O- RING 13.2×2.65	1
4	E12060003	CAP, SMALL VIEW HOLE	TAPON DE INSPECCION	1
5	E09030006	O-RING 13.2×2.65	O-RING 13.2×2.65	1
6	E09030002	O-RING 62×3	O- RING 62×3	1
7	E12010029	COVER, DOUBLE GEAR	CUBIERTA DE REDUCTOR DE ENGRANAJE	1
8	E07040058	BOLT M6×20	TORNILLO M6×20	3
9	E12010027	REAR PART, LEFT CRANKCASE COVER	CUBIERTA TRASERA DE TAPA MOTOR	1
10	E12060019	BOLT M6×28	TORNILLO M6×28	2
11	E09050035	BOLT M6×40	TORNILLO M6×40	5
12	E04060080	BOLT M6×50	TORNILLO M6×50	2
13	E12060018	BOLT M6×25	TORNILLO M6×25	1
14	E09030001	GASKET, FRONT COVER, LEFT CRANK	EMPAQUETADURA DE CUBIERTA	1
15	E04060013	DOWEL PIN 10×14	GUÍA 10×14	2



E13 = 启动马达 / STARTING MOTOR / ARRANQUE DE MOTOR				
ITEM	UM Part #	Description	Spanish	Qty
1	E13010017	STARTING MOTOR ASSY, SILVER	CONJ MOTOR DE ARRANQUE	1
2	E13030021	BEARING 6.5×12×5.8	BALERO 6.5×12×5.8	2
3	E07040013	BOLT M6×28	TORNILLO M6×28	2
4	E13020031	GEAR,CONNECTED,1	ENGRANAJE DUAL (1)	1
5	E13010004	GEARSHAFT,CONNECTED	EJE DE ENGRANAJE DUAL (1)	1
6	E13020030	GEAR,CONNECTED,2	ENGRANAJE DUAL (2)	1
7	E13030003	WASHER 10.5×0.5×18	ARANDELA 10.5×0.5×18	4
8	E13020004	STARTER CLUTCH COMP.	EMBRAGUE DE ARRANQUE	1
9	E13010016	STARTER GEAR	CONJ ENGRANAJE DE ARRANQUE	1
10	E13030023	WASHER 22×6.0×34	ARANDELA 22×6.0×34	1
11	E13030022	WASHER 22×2.5×34	ARANDELA 22×2.5×34	1
12	E13030020	PLASSURE PLATE, STARTING GEAR	PLETINA DE SUJECION	1
13	E01060040	BOLT M6×12	TORNILLO M6×12	1



1



2



3



4



5



6

E14 = 传动系统 / TRANSMISSION / TRANSMISION


ITEM	UM Part #	Description	Spanish	Qty
1	E14020004	ASSEMBLY, MAINSHAFT	EJE PRIMARIO COMPLETO	1
2	E14020019	ASSEMBLY, COUNTERSHAFT	EJE CONDUCTOR COMPLETO	1
3	E14010016	DRIVE SPROCKET	PIÑÓN DELANTERO	1
4	E14040001	FIXING PLATE, DRIVE SPROCKET	PLACA FIJA	1
5	E14040003	BOLT M6×10	PERNO M6×10	2
6	E14020018	ASSEMBLY, KICK STARTING SHAFT	EJE DE ARRANQUE COMPLETO	1




E14 = 散热系统 / RADIATOR & HOSES / RADIADOR Y MANGUERAS				
ITEM	UM Part #	Description	Spanish	Qty
1	B13020002	OIL COOLER	RADIADOR DE ACEITE	1
2	B13010004	PIPE,OIL COOLER II	MANGUERA LARGA	1
3	B13010003	PIPE,OIL COOLER I	MANGUER CORTA	1
4	B13030001	BOLT M8×25	TORNILLO M8x25	4
5	B13030002	COPPER WISHER 8.2×1×14	ARANDELA DE COBRE 8.2×1×14	8



B01 = 空滤器 / AIR CLEANER ASSY / FILTRO DE AIRE			
ITEM	UM Part #	Description	Spanish
1	B01020027	AIR FILTER ASSY	CONJUNTO DE FILTRO DE AIRE
2	B01010021	ELEMENT FILTER	ELEMENTO DEL FILTRO DE AIRE
3	B01030016	TOOL SET	KIT DE HERRAMIENTAS




B02 = 电器件 / ELECTRIC SYSTEM / SISTEMA ELECTRICO			
ITEM	UM Part #	Description	Spanish
1	B02060015	IGNITION COIL ASSY	BOBINA DE IGNICION
2	B02030013	RECTIFIER	RECTIFICADOR/REGULADOR
3	B02020019	STRATING RELAY	RELE DE ARRANQUE
4	B02040013	CDI	UNIDAD CDI
5	B02020021	FLASHER	RELE DIRECCIONALES
6	B02080015	HORN ASSY	CLAXON
7	B02050027	HARNESS	ARNES ELECTRICO
8	B02010015	BATTERY	BATERIA YTX7A-BS




B03 = 挡泥板 / FENDERS / GUARDABARRO			
ITEM	UM Part #	Description	Spanish
1	B03010082	FRONT FENDER(BLACK)	SALPICADERA DEL. NEGRO
1	B03010080	FRONT FENDER(RED)	SALPICADERA DEL. ROJO
1	B03010081	FRONT FENDER(BASE COLOR)	SALPICADERA DEL. COLOR BASE
2	B03020015	RR.FENDER,FR.	SALPICADERA INTERNA TRAS.
3	B03040024	RR,SECTION,RR.FENDER	SALPICADERA TRAS.
4	B03060057	BRACKET,RR.LICENSE	BASE PORTA PLACA
5	B03020014	LOWER FENDER	SALPICADERA INFERIOR




B04 = 脚踏、启动杆 & 变档杆 / FOOTREST & PEDALS / POSAPIE Y PEDALES			
ITEM	UM Part #	Description	Spanish
1	B04030046	COVER,PILLION STEP R.	SOPORTE DER. REPOSAPIE TRAS
2	B04090110	BRACKET	BASE
3	B04090113	BRACKET	BASE
4	B04030048	R.RR.FOOTREST ASSY	POSAPIE TRASERO DER.
5	B04030048	FR.FOOTREST,R.	POSAPIE DERECHO DEL.
6	B04030045	COVER,PILLION STEP L.	SOPORTE IZQ. REPOSAPIE TRAS.
7	B04090112	BRACKET	BASE
8	B04030047	L.RR.FOOTREST ASSY	POSAPIE TRASERO IZQ.
9	B04030047	FR.FOOTREST,L.	POSAPIE IZQUIERDO DEL.
10	B04060026	RR.BRAKE ARM	PEDAL DE FRENO
11	B04090109	RETURN SPRING,RR.BRAKE PEDAL	RESORTE PEDAL DE FRENO
12	B04070015	GEARSHIFT ASSY	CONJUNTO PEDAL DE CAMBIOS
13	B04080020	KICK START ASSY	PEDAL DE ARRANQUE
14	B04050036	SIDE STAND	PARADOR LATERAL
15	B04090114	BOLT	TORNILLO PARADOR LATERAL
16	B04090115	HEXAGON NUTS WITH FLANGE M6	TUERCA HEXAGONAL M10
17	B04090111	SPRING, SIDE STAND	RESORTE PARADOR LATERAL




B05 = 车架，安装板和支架 / FRAME, PLATE & BASE / CHASIS Y BASES			
ITEM	UM Part #	Description	Spanish
1	B05010026	FRAME	CUADRO
2	B05030050	PREVAILING TORQUE TYPE ALL-METAL	TUERCA, M8
3	B05030046	HEXAGON FLANGE BOLTS—SMALL SERIES	PERNO HEX. M8×65
4	B05020087	PLATE,ENGINE RIGHT UP HANGER.,R	PLATINA SUJ. MOTOR SUPERIOR
5	B05020086	PLATE,ENGINE RIGHT UP HANGER.,L	PLATINA SUJ. MOTOR SUPERIOR
6	B05020094	FRAME BASE	BASE DE CUADRO
7	B05020093	FRAME BASE	BASE DE CUADRO
8	B05020091	FRAME BASE	BASE DE CUADRO
9	B05020090	FRAME BASE	BASE DE CUADRO
10	B05020092	FRAME BASE	BASE DE CUADRO
11	B05020085	PLATE,ENGINE FR.HANGER	PLATINA MOTOR INF. FRONTAL
12	B05030047	HEXAGON FLANGE BOLTS—SMALL SERIES	PERNO HEX. M8X75
13	B05030048	HEXAGON FLANGE BOLTS—SMALL SERIES	PERNO HEX. M8X85
14	B05030051	PREVAILING TORQUE TYPE ALL-METAL	TUERCA, M10
15	B05030049	HEXAGON FLANGE BOLTS—SMALL SERIES	PERNO HEX. M10x110
16	B05020089	FRAME BASE	BASE DE CUADRO
17	B05020088	FRAME BASE	BASE DE CUADRO
18	B05020081	FRAME BASE	BASE DE CUADRO
19	B05020083	FRAME BASE	BASE DE CUADRO
20	B05020084	FRAME BASE	BASE DE CUADRO
21	B05020082	FRAME BASE	BASE DE CUADRO




B06 = 前轮 & 前刹车 / FRONT WHEEL & BRAKE ASSY / RUEDA DELANTERA Y FRENO DELANTERO			
ITEM	UM Part #	Description	Spanish
1	B06050020	R.SPACER,FR.WHEEL φ21×φ12×32	ESPACIADOR DER. RUEDA DEL.
2	B06030045	FR.WHEEL ASSY	RIN COMPLETO DEL.
3	B06050019	BEARING 6301-2RS	RODAMIENTO 6301-2RS
4	B06010016	OUTER TUBE,FR.WHEEL	LLANTA DEL
5	B06010017	Air nottle	VALVULA DE AIRE
6	B06080065	FR.BRAKING DISC	DISCO DE FRENO DEL
7	B06100064	BOLT M8×25	PERNO M8×25
8	B06080066	DISH BRAKE ASS'Y,FR	CONJUNTO DE FRENO DELANTERO
9	B06060017	CALIPER ASSY,FR.	CONJUNTO CALIPER
10	B06070017	LOWER PAD	BALATA DEL.
11	B08030033	FRONT BRAKE LEVER	MANIGUETA DE FRENO DEL.
12	B06080067	UP DISK BRAKE CYLINDER ASSY	CONJUNTO BOMBA DE FRENO DEL.
13	B06080068	BRAKE HOSE COMP	MANGUERA DE FRENO DEL.
14	B06090012	SENSOR, SPEEDER &=36mm	ARAÑA DE VELOCIMETRO &=36mm
15	B06100065	PREVAILING TORQUE TYPE ALL-METAL	TUERCA M12×1.25
16	B06050018	SHAFT,FR.WHEEL M12×245	EJE DE LA RUEDA DELANTERA




B07 = 油箱 / FUEL TANK / TANQUE DE COMBUSTIBLE			
ITEM	UM Part #	Description	Spanish
1	B07010065	FUEL TANK(BLACK)	TANQUE COMBUSTIBLE NEGRO
1	B07010063	FUEL TANK(RED)	TANQUE COMBUSTIBLE ROJO
1	B07010064	FUEL TANK(BASE COLOR)	TANQUE COMBUSTIBLE SIN PINTAR
2	B07070032	FUEL TANK FRONT BUFFERING RUBBER	CAUCHO ANTIVIBRANTE FRONTAL,
3	B07070033	FUEL TANK REAR BUFFERING RUBBER	CAUCHO ANTIVIBRANTE TRASERO,
4	B07040013	INLET OIL PIPE 245mm	CONDUCTO DE ADMISIÓN
5	B07030011	FUEL COCK	LLAVE DE PASO COMBUSTIBLE
6	B07040014	INLET OIL PIPE 245mm	Qty
7	B07040011	OIL CUP	FILTRO DE GASOLINA
8	B07050012	FUEL TANK SENSOR	UNIDAD SENSORA DE



B08 = 方向把 / HANDLE BAR / MANUBRIO			
ITEM	UM Part #	Description	Spanish
1	B08050025	STEEARING BAR	MANUBRIO
2	B08020039	BALANCE BLOCK	CONTRAPESO
3	B08020038	GRIP,R.HANDLE BAR	PUÑO DE ACELERADOR
4	B08020037	GRIP,L.HANDLE BAR	PUÑO IZQUIERDO
5	B08040022	CLAMP,HANDLE BAR	ABRAZADERAS DE MANUBRIO
7	B08040021	HOLDER SEAT,HANDLE BAR	ELEVADOR DE MANUBRIO
8	B08030032	LEFT LEVER	PALANCA IZQUIERDA
9	B08010027	MIRROR,REAR R	ESPEJO DER.
6	B08010026	MIRROR,REAR L	ESPEJO IZQ.




B09 = 灯具 / LIGHTS / LUCES DIRECCIONALES Y REFLEJANTES			
ITEM	UM Part #	Description	Spanish
1	B09010026	FR.HEADLIGHT ASSY	CONJUNTO DE FARO COMPLETO
2	B09040066	HIGH BEAM BULB	FOCO DE FARO
3	B09040065	BEAM BULB	FOCO LUZ NEUTRAL
4	B09030050	FR,L.TURNSIGNAL LIGHT	DIRECCIONAL DELANTERA
5	B09030051	FR,R.TURNSIGNAL LIGHT	DIRECCIONAL DELANTERA
6	B09020027	TAIL LIGHT ASSY	CONJUNTO DE CALAVERA
7	B09020026	LICENSE LIGHT ASSY	CONJUNTO LUZ PORTAPLACA
8	B09040062	BULB	FOCO LUZ PORTAPLACA




B10 = 仪表、钢索、锁具和开关 / METER, CABLES, LOCKS & SWITCH / VELOCIMETRO, GUAYAS Y CERR


ITEM	UM Part #	Description	Spanish
1	B10010024	ODOMETER ASSY	CONJUNTO VELOCIMETRO
2	B10050026	L.HANDLE SWITCH	CONJUNTO DE MANDO IZQUIERDO
3	B10050027	R.HANDLE SWITCH	CONJUNTO DE MANDO DERECHO
4	B10020026	LOCK ASSY	JUEGO COMPLETO DE
5	B10030057	Cable,cushion	GUAYA SEGURO ASIENTO
6	B10030056	CABLE,CHOKE	CHICOTE DE AHOGADOR
7	B10030054	CABLE,THROTTLE	CHICOTE DE ACELERADOR
8	B10030055	CABLE,CLUTCH	CHICOTE DE CLUTCH




B11 = 消声器 / MUFFLER ASSY / ESCAPE			
ITEM	UM Part #	Description	Spanish
1	B11010069	MUFFLER ASSY	CONJUNTO DE ESCAPE
2	B11010071	EXHAUST PIPE	CURVA MOFLE
3	B11010072	EXHAUST PIPE	CURVA MOFLE
4	B11010070	MUFFLER TAIL	COLA DE ESCAPE
5	B11040041	RUBBER	GOMAS
6	B11040040	NUT,HEX	TUERCA HEX
7	B11030014	PROTECTOR	CUBIERTA DE ESCAPE
8	B11030013	PROTECTOR	CUBIERTA DE ESCAPE
9	B05030050	NUT,ROUND	TUERCA
10	B11040039	GASKET,MUFFLER	EMPAQUE DE ESCAPE




B12 = 塑料件和贴花 / PLASTIC COVERS & STICKERS / PLASTICOS Y STICKERS			
ITEM	UM Part #	Description	Spanish
1	B12020094	HEADLIGHT COVER (BLACK)	CUBIERTA DE FARO NEGRA
2	B12030023	RIGHT COVER, HEADLIGHT COVER (BLACK)	SOPORTE DERECHO CARENAJE
3	B12030022	LEFT COVER,HEADLIGHT COVER (BLACK)	SOPORTE IZQUIERDO CARENAJE
4	B12010602	FUEL TANK COVER AND LED HOUSE, RIGHT	CUBIERTA DE TANQUE DE GAS
4	B12010603	FUEL TANK COVER AND LED HOUSE, RIGHT	CUBIERTA DE TANQUE DE GAS
5	B12010604	FUEL TANK COVER AND LED HOUSE, LEFT	CUBIERTA DE TANQUE DE GAS
5	B12010605	FUEL TANK COVER AND LED HOUSE, LEFT	CUBIERTA DE TANQUE DE GAS
6	B12010608	RIGHT FUEL TANK DECORATIVE BAR (BLACK)	BARRA DERECHA, TANQUE DE
7	B12010607	LEFT FUEL TANK COVER (BLACK)	BARRA IZQUIERDA, TANQUE DE
8	B12010609	DECORATIVE COVER RIGHT	CUBIERTA DECORATIVA DERECHA
9	B12010598	COVER SUB ASSY,R.SIDE (BLACK)	PROTECTOR LATERAL DER.NEGRO
10	B12010591	COVER SUB ASSY,L.SIDE (BLACK)	PROTECTOR LATERAL IZQ. NEGRO
11	B12010597	SIDE COVER RIGHT (BLACK)	TAPA LATERAL DER. NEGRO
11	B12010596	SIDE COVER RIGHT (BASE COLOR)	TAPA LATERAL DER. SIN PINTAR
11	B12010595	SIDE COVER RIGHT (RED)	TAPA LATERAL DER. ROJA
12	B12010594	SIDE COVER LEFT (BLACK)	TAPA LATERAL IZQ. NEGRO
12	B12010593	SIDE COVER LEFT (BASE COLOR)	TAPA LATERAL IZQ. SIN PINTAR
12	B12010592	SIDE COVER LEFT (RED)	TAPA LATERAL IZQ. ROJA
13	B12010588	CENTER COVER RR (RED)	TAPA TRASERA ROJA
13	B12010590	CENTER COVER RR (BLACK)	TAPA TRASERA NEGRA
13	B12010589	CENTER COVER RR (BASE COLOR)	TAPA TRASERA SIN PINTAR
14	B12010606	DECORATIVE COVER LEFT	IZQUIERDA



B13 = RADIATOR & HOSES / RADIADOR Y MANGUERAS			
ITEM	UM Part #	Description	Spanish
1	B12010600	DECORATIVE COVER	CUBIERTA DECORATIVA
2	B12010601	RIGHT CYLINDER COVER (BLACK)	CUBIERTA DERECHA DE CIINDRO
3	B12010599	LEFT CYLINDER COVER (BLACK)	CUBIERTA IZQUIERDA DE CIINDRO
4	B12010611	UPPER FRAME COVER LEFT (BASE COLOR)	CUBIERTA SUPERIOR DE CUADRO
4	B12010615	UPPER FRAME COVER LEFT (RED)	CUBIERTA SUPERIOR DE CUADRO
4	B12010619	UPPER FRAME COVER LEFT (SILVER)	CUBIERTA SUPERIOR DE CUADRO
5	B12010613	LOWER FRAME COVER LEFT (BASE COLOR)	CUBIERTA INFERIOR DE CUADRO
5	B12010617	LOWER FRAME COVER LEFT (RED)	CUBIERTA INFERIOR DE CUADRO
5	B12010621	LOWER FRAME COVER LEFT (SILVER)	CUBIERTA INFERIOR DE CUADRO
6	B12010610	UPPER FRAME COVER RIGHT (BASE	CUBIERTA SUPERIOR DE CUADRO
6	B12010614	UPPER FRAME COVER RIGHT (RED)	CUBIERTA SUPERIOR DE CUADRO
6	B12010618	UPPER FRAME COVER RIGHT (SILVER)	CUBIERTA SUPERIOR DE CUADRO
7	B12010612	LOWER FRAME COVER RIGHT (BASE COLO	CUBIERTA INFERIOR DE CUADRO
7	B12010616	LOWER FRAME COVER RIGHT (RED)	CUBIERTA INFERIOR DE CUADRO
7	B12010620	LOWER FRAME COVER RIGHT (SILVER)	CUBIERTA INFERIOR DE CUADRO
8	B12040093	UM EMBLEM	EMBLEMA UM



B14 = 后摇架 / REAR FORK / HORQUILLA TRASERA			
ITEM	UM Part #	Description	Spanish
1	B14020029	RR.SHORK ABSORBER COMP	AMORTIGUADOR TRASERO
2	B14020028	ROD SUB-ASSY., SHOCK CONNECTING	BRAZO INFERIOR SUSPENSION
3	B14020027	ARM SUB-ASSY., CUSHION	SOPORTE BRAZO SUSPENSION
4	B14010024	SWING ARM	HORQUILLA TRASERA
5	B14030055	SHAFT,SWING ARM	EJE DE HORQUILLA TRASERA
6	B14030056	PREVAILING TORQUE TYPE ALL-METAL HE	TUERCA M12



B15 = 后轮 & 后刹车 / REAR WHEEL & BRAKE ASSY / RUEDA TRASERA Y FRENO TRASERO			
ITEM	UM Part #	Description	Spanish
1	B15090057	CHAIN 520H*132	CADENA DE TRACCION 520 x 132
2	B15090056	SLIDER,CHAIN	DESLIZADOR CADENA
3	B15110013	ADJUST, CHAIN	AJUSTADOR DE CADENA
4	B15050049	L.SPACER,RR.WHEEL SHAFT	ESPACIADOR IZQ. RUEDA TRAS.
5	B15080030	REAR DISK BRAKE, FIXED BRACKET	BASE DEL CONJUNTO DISCO DE
6	B06100064	REAR DISK BRAKE BOLT, M8X25	TORNILLO M8X25DISCO FRENO
7	B15080028	REAR WAVE BRAKE DISC 240mm×4mm	DISCO DE FRENO DIBUJADO,
8	B15080029	DISH BRAKE ASS'Y,RR , GOLD COLOR+	CONJUNTO DE FRENO TRASERO
9	B15080031	UP DISK REAR BRAKE CYLINDER ASSY A	CONJUNTO CILINDRO A, FRENO
10	B14030056	PREVAILING TORQUE TYPE ALL-METAL HE	TUERCA M14
11	B15050045	SHAFT,RR.WHEEL	EJE DE LA RUEDA TRASERA
12	B15060009	DOWN REAR BRAKE CYLINDER A	CILINDRO A INFERIOR, FRENO
13	B15070015	REAR DISK PADS ASSY	JGO. PASTILLAS FRENO TRASERO
14	B15080032	BRAKE OIL TUBE B	MANGUERA
15	B15050048	R.SPACER,RR.WHEEL SHAFT	ESPACIADOR DER. RUEDA TRAS.
16	B15030056	RIM ASSY	RIN COMPLETO TRAS.
17	B15050046	BEARING 6302	RODAMIENTO 6302
18	B15130052	HEXAGON NUTS,STYLE 1 M8	TUERCA HEX M8
19	B15010017	TIRE ,RR.WHEEL	LLANTA TRAS 130/90-15, 66P
20	B06010017	Air nottle	VALVULA DE AIRE
21	B15120019	DAMPER CUSHION	MAZA DE RIN TRASERO
22	B15120018	REAR WHEEL HUB	DAMPER DE TRACCION
23	B15050050	INNER COLLAR	BUJE INTERNO
24	B15050047	OIL SEAL	SELLO DE ACEITE
25	B15100025	SPROCKET,FINAL DRIVE 32	POTENCIADOR FINAL 32
26	B15120020	BOLT, FINAL DRIVEN	TORNILLO DEL SPROCKET



B16 = 坐垫 & 后货架 / SEAT & RACK / ASIENTOS Y PARRILLAS

ITEM	UM Part #	Description	Spanish
1	B16010028	FR.SEAT COMP	ASIENTO DELANTERO
2	B16010029	RR.SEAT COMP	ASIENTO TRASERO
3	B16020022	R.BRACKET,BACK	BASE DERECHA DE RESPALDO
4	B16020021	L.BRACKET,BACK	BASE IZQUIERDA DE RESPALDO

The diagram illustrates the assembly of front suspension components. On the left, two vertical shock absorbers are shown, labeled 1 (Right Front Shock Absorber) and 2 (Left Front Shock Absorber). To their right is a steering knuckle assembly, labeled 3, which includes a steering stem and a bearing assembly (4). A cable clamp (7) is shown separately. On the far right, a vertical stack of components is shown, including a nut (8), a washer (9), a bearing assembly (6), a dust seal (5), and a steering stem (3). The bearing assembly (4) is shown in a separate view, highlighting its internal components.

B17 = 方向柱、前減 / STEERING STEM, FRONT SHOCK ABSORBER / SUSPENSION DELANTERA			
ITEM	UM Part #	Description	Spanish
1	B17020012	R.FR.SHORK ABSORBER	AMORTIGUADOR DELANTERO
2	B17030014	L.FR.SHORK ABSORBER	AMORTIGUADOR DELANTERO
3	B17010018	STEERING STEM	TELESCOPIO DE DIRECCION
4	B17050092	BEARING ASSY	KIT DE BALEROS DE DIRECCION
5	B17050088	CAP, DUST SEAL	GUARDAPOLVO SUSPENSION
6	B17050091	ADJUST NUT,STEERING STEM	TUERCA DE COMPRESIÓN
7	B17070079	CABLE CLAMP,FRONT DISC BRAKE	SUJETADOR MANGUERA, DISCO
8	B17050090	NUT	TUERCA M22
9	B17050089	WASHER	ARANDELA

1



A01 = 配件 / ACCESSORY/ACCESORIOS

ITEM	UM Part #	Description	Spanish	qty
1	A01010001	ACCESSORY REAR RACK AND PLASTIC COVERS	KIT PARRILLA	1