


PARTS BOOK



***RENEGADE
LIMITED 2000CC***




www.umglobal.com



B01 = 空滤器 / AIR CLEANER ASSY / FILTRO DE AIRE

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	490-0031A	B01020002	空滤器总成	AIR FILTER ASSY	CONJUNTO DE FILTRO DE AIRE	1	B0102
2	490-0035A	B01010002	滤芯	ELEMENT FILTER	ELEMENTO DEL FILTRO DE AIRE	1	B0101




B02 = 电器件 / ELECTRIC SYSTEM / SISTEMA ELECTRICO

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	350-0035A	B02050002	主电缆	HARNESS	ARNES ELECTRICO	1	B0205
2	312-0010A	B02010002	蓄电池	BATTERY	BATERIA YTX7A-BS	1	B0201
3	337-0066A	B02020003	闪光器	FLASHER	RELE DIRECCIONALES	1	B0202
4	313-0022A	B02060002	点火线圈总成	IGNITION COIL ASSY	BOBINA DE IGNICION	1	B0206
5	970-0084A	B02090001	电瓶盒支架	BRACKET,TOOL BOX	BASE BATERIA	1	B0209
6	313-0025A	B02020004	启动继电器	STRATING RELAY	RELE DE ARRANQUE	1	B0202
7	311-0017A	B02030002	调压整流器	RECTIFIER	RECTIFICADOR/REGULADOR	1	B0203
8	313-0026A	B02040002	点火器	IGNITION	UNIDAD CDI	1	B0204
9	343-0010A	B10020003	后刹开关线	REAR BRAKE SWITCH CABLE	INTERRUPTOR DE LUZ DE FRENO	1	B1002
10	337-0062A	B02080002	喇叭总成	HORN ASSY	CLAXON	2	B0208
11	343-0013A	B02090002	后制动灯开关簧	SWITCH,RR.BRAKE LIGHT	RESORTE DEL INTERRUPTOR	1	B0209
12	970-0085A	B02090003	蓄电池箍带	BAND,BATTERY	GOMA SUJETADORA BATERIA	1	B0209




B03 = 挡泥板 / FENDERS / GUARDABARRO

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	111-0017A	B03010015	前挡泥板(黑色)	FRONT FENDER(BLACK)	SALPICADERA DEL. NEGRO	1	B0301
1	111-0018A	B03010016	前挡泥板(银色)	FRONT FENDER(SILVER)	SALPICADERA DEL. PLATA	1	B0301
1	111-0019A	B03010017	前挡泥板(钛金色)	FRONT FENDER(TITANIUM)	SALPICADERA DEL. TITANIO	1	B0301
2	170-0045A	B03040001	后挡泥板后段(黑色)	RR,SECTION,RR.FENDER(BLACK)	SALPICADERA TRAS. NEGRO	1	B0304
2	170-0046A	B03040002	后挡泥板后段(银色)	RR,SECTION,RR.FENDER(SILVER)	SALPICADERA TRAS. PLATA	1	B0304
2	170-0047A	B03040003	后挡泥板后段(钛金色)	RR,SECTION,RR.FENDER(TITANIUM)	SALPICADERA TRAS. TITANIO	1	B0304
3	170-0038A	B03020010	后挡泥板前段	RR.FENDER,FR.	SALPICADERA INTERNA TRAS.	1	B0302
4	970-0086A	B03030002	后挡泥板内衬	INNER BUSH,RR.FENDER	BASE SALPICADERA TRAS.	1	B0303
5	170-0039A	B03060002	后挡泥板中段	RR.FENDER,MD	BASE SALPICADERA DEL.	1	B0306
6	970-0087A	B03060003	后牌照支架	BRACKET,RR.LICENSE	BASE PORTA PLACA	1	B0306
7	970-0088A	B03060004	后牌照支架内衬	INNER BUSH,RR.LICENSE	BASE DE LUZ PORTAPLACA	1	B0306




B04 = 脚踏、启动杆 & 变档杆 / FOOTREST & PEDALS / POSAPIE Y PEDALES

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	211-0047A	B04020005	左脚踏板	FR.FOOTREST,L.	GOMA POSAPIE IZQUIERDO DEL.	1	B0402
2	211-0046A	B04040001	前左脚踏胶垫	RUBBER,FR.FOOTREST L.	POSAPIE IZQUIERDO DEL.	1	B0404
3	211-0048A	B04040002	前右脚踏胶垫	RUBBER,FR.FOOTREST R.	GOMA POSAPIE DERECHO DEL.	1	B0404
4	211-0049A	B04020006	右脚踏板	FR.FOOTREST,R.	POSAPIE DERECHO DEL.	1	B0402
5	970-0040A	B04030007	左后脚踏总成	L.RR.FOOTREST ASSY	POSAPIE TRASERO IZQ.	1	B0403
6	470-0156A	B04030008	右后脚踏总成	R.RR.FOOTREST ASSY	POSAPIE TRASERO DER.	1	B0403
7	940-0051A	B04090003	侧支架弹簧	SPRING, SIDE STAND	RESORTE PARADOR LATERAL	1	B0409
8	252-0132A	B04060003	后制动臂	RR.BRAKE ARM	PEDAL DE FRENO	1	B0406
9	270-0092A	B04060004	制动臂连接杆	CONNECTION ROD	IMPULSOR DE PEDAL DE CAMBIOS	1	B0406
10	211-0052A	B04060005	刹车拉杆总成	BRAKE ROD ASSY	VARILLA DE FRENO	1	B0406
11	270-0095A	B04060006	花键轴	SPLINE SHAFT	EJE TRANSMISOR PEDAL CAMBIOS	1	B0406
12	270-0096A	B04060007	旋转臂	ROTATE ARM	BRAZO ACTUADOR PEDAL CAMBIOS	1	B0406
13	212-0026A	B04050002	侧支架	SIDE STAND	PARADOR LATERAL	1	B0405
14	916-0118A	B04090004	螺栓	BOLT	TORNILLO PARADOR LATERAL	1	B0409
15	940-0058A	B04040003	后制动踏板胶垫	RUBBER PLATE RR.BRAKE PEDEL	GOMA PEDAL DE FRENO	1	B0404
16	980-0059A	B04040004	换挡臂胶套	RUBBER GEAR CHANGE	GOMA PEDAL DE CAMBIOS	2	B0404
17	980-0060A	B04040005	启动臂胶套	RUBBER SLEEVE STARTING ARM	GOMA PEDAL DE ARRANQUE	1	B0404
18	435-005A	B04080002	启动臂总成	KICK START ASSY	PEDAL DE ARRANQUE	1	B0408
19	940-0053A	B04090005	后制动臂回位簧	RETURN SPRING,RR.BRAKE PEDAL	RESORTE PEDAL DE FRENO	1	B0409
20	270-0099A	B04070002	换挡臂总成	GEARSHIFT ASSY	CONJUNTO PEDAL DE CAMBIOS	1	B0407



B05 = 车架, 安装板和支架 / FRAME, PLATE & BASE / CHASIS Y BASES

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	210-0059A	B05010002	车架	FRAME	CUADRO	1	B0501
2	970-0077A	B05020002	发动机前悬挂	FR.SUSPENSION	BASE DE MOTOR DELANTERO	1	B0502
3	211-0045A	B05020003	前脚踏板支架	BRACKET.FR.FOOTRST	BASE DE POSAPIES DELANTEROS	1	B0502
4	970-0081A	B05020004	左后脚踏支架	BRACKET,L.RR.FOOTREST	BASE DE POSAPIES TRASEROS DER	1	B0502
5	970-0082A	B05020005	发动机右上悬挂	UPPER SUSPENSION R.	BASE SUPERIOR IZQUIERDA MOTOR	1	B0502
6	970-0083A	B05020006	车头右护板支架	BRACKET R.PROTECTION PLATE	BASE CUBIERTA DEC IZQ	1	B0502
7	970-0078A	B05020007	右后脚踏支架	BRACKET,R.RR.FOOTREST	BASE DE POSAPIES TRASEROS IZQ	1	B0502
8	970-0079A	B05020008	发动机左上悬挂	UPPER SUSPENSION L.	BASE SUPERIOR DERECHA MOTOR	1	B0502
9	970-0080A	B05020009	车头左护板支架	BRACKET L.PROTECTION PLATE	BASE CUBIERTA DEC DER	1	B0502




B06 = 前轮 & 前刹车 / FRONT WHEEL & BRAKE ASSY / RUEDA DELANTERA Y FRENO DELANTERO

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	261-0071A	B06010003	前轮外胎 3.00-18	OUTER TUBE,FR.WHEEL 3.00-18	LLANTA DEL 110/90-16	1	B0601
2	261-0065A	B06030006	前轮总成	FR.WHEEL ASSY	RIN COMPLETO DEL. 2.15 x 18	1	B0603
3	251-0107A	B06080003	前碟刹盘	FR.BRAKING DISC	DISCO DE FRENO DEL.	1	B0608
4	251-0082A	B06080004	制动胶管组合	BRAKE HOSE COMP	MANGUERA DE FRENO DEL.	1	B0608
5	261-0037A	B06050004	前轮轴	SHAFT,FR.WHEEL	EJE DE LA RUEDA DELANTERA	1	B0605
6	261-0074A	B06050005	前轮右衬套	R.SPACER,FR.WHEEL	ESPACIADOR DER. RUEDA DEL.	1	B0605
7	251-0091A	B06060003	前制动钳组合	CALIPER ASSY,FR.	CONJUNTO CALIPER ABS.	1	B0606
8	251-0094A	B06070002	下塞片	LOWER PAD	BALATA DEL.	2	B0607
9	931-0026A	B06040003	前轮调节螺母	ADJUSTING NUT, SPOKE,FR. WHEEL	TUERCA DE RAYO	72	B0604
10	261-0075A	B06040004	轴条	SPOKE,FR.WHEEL	RAYO DEL.	36	B0604
11	261-0076A	B06020003	前轮内胎	INNER TUBE,FR.WHEEL	CAMARA DE AIRE RUEDA DELANTERA	1	B0602
12	923-0009A	B06100002	前轮油封	OIL SEAL	SELLO DE ACEITE	1	B0610
13	960-0004A	E05030003	前轮轴承	BEARING 6202	RODAMIENTO 6202	1	B0610
14	923-0018A	B06100003	密封圈	SEAL RING	SELLO DE ACEITE	1	B0610
15	251-0092A	B06060004	ABS总成	ABS ASSY	ELEMENTO ABS	1	B0606
16	261-0088A	B06020004	前轮垫带	PROTECTOR,FR.WHEEL	PROTECTOR DE RIN DELANTERO	1	B0602



B07 = 油箱 / FUEL TANK / TANQUE DE COMBUSTIBLE

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	221-0078A	B07010002	油箱(黑色)	FUEL TANK(BLACK)	TANQUE COMBUSTIBLE NEGRO	1	B0701
1	221-0079A	B07010003	油箱 (银色)	FUEL TANK(SILVER)	TANQUE COMBUSTIBLE PLATA	1	B0701
1	221-0080A	B07010004	油箱 (钛金色)	FUEL TANK(TITANIUM)	TANQUE COMBUSTIBLE TITANIO	1	B0701
2	222-0029A	B07030002	油开关	FUEL COCK	LLAVE DE PASO COMBUSTIBLE	1	B0703
3	221-0055A	B07070001	后油箱胶	RR.CUSHION, OIL FILTER	BASE DE TANQUE GAS.	1	B0707
4	222-0028A	B07040002	油杯	OIL CUP	FILTRO DE GASOLINA	1	B0704
5	343-0014A	B07050001	传感器	FUEL TANK SENSOR	UNIDAD SENSORA DE COMBUSTIBLE	1	B0705
6	335-0002A	B07050002	燃油表	METER,FUEL LEVER	MEDIDOR DE NIVEL GAS.	1	B0705




B08 = 方向把 / HANDLE BAR / MANUBRIO

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	270-0083A	B08010003	左后视镜	L,REAR-VIEW MIRROW	ESPEJO RETROVISOR	1	B0801
2	230-0017A	B08050002	方向把管	STEEARING BAR	MANUBRIO	1	B0805
3	270-0086A	B08040004	手把管卡子	CLAMP,HANDLE BAR	ABRAZADERAS DE MANUBRIO	2	B0804
4	270-0087A	B08020003	左手把胶组合	GRIP,L,HANDLE BAR	PUÑO IZQUIERDO	1	B0802
5	270-0088A	B08020004	右手把胶组合	GRIP,R,HANDLE BAR	PUÑO DE ACELERADOR	1	B0802
6	270-0122A	B08030003	离合手柄总成	CLUTCH HANDLE ASSY	BASE DE PALANCA IZQUIERDA	1	B0803
7	270-0090A	B08040005	手把管卡座	HOLDER SEAT,HANDLE BAR	ELEVADOR DE MANUBRIO	2	B0804
8	270-0289A	B08030004	离合手柄	LEFT LEVER	PALANCA IZQUIERDA	1	B0803
9	251-0083A	B08030005	制动手柄	BRAKE HANDLE	PALANCA DERECHA	1	B0803
10	251-0081A	B06080005	制动泵组合	BRAKE OIL PUMP COMP	BOMBA DE FRENO DEL.	1	B0608
11	910-0092A	B08060001	枢轴螺栓	BOLT,SPINDLE	TORNILLO FIJADOR PALANCA	1	B0806




B09 = 灯具 / LIGHTS / LUCES DIRECCIONALES Y REFLEJANTES

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	337-0068A	B09030005	前左转向灯	FR,L.TURNSIGNAL LIGHT	DIRECCIONAL DELANTERA IZQUIERDA	1	B0903
2	337-0069A	B09030006	前右转向灯	FR,R.TURNSIGNAL LIGHT	DIRECCIONAL DELANTERA DERECHA	1	B0903
3	337-0070A	B09040004	灯泡	BULB	FOCO DE DIRECCIONAL	4	B0904
4	337-0071A	B09030007	后左转向灯	RR,L.TURNSIGNAL LIGHT	DIRECCIONAL IZQUIERDA TRASERA	1	B0903
5	337-0072A	B09030008	后右转向灯	RR,R.TURNSIGNAL LIGHT	DIRECCIONAL DERECHA TRASERA	1	B0903
6	332-0062A	B09020002	尾灯总成	TAIL LIGHT ASSY	CONJUNTO DE CALAVERA TRASERA	1	B0902
7	331-0041A	B09010002	前大灯总成	FR.HEADLIGHT ASSY	CONJUNTO DE FARO COMPLETO	1	B0901
8	331-0054A	B09040005	尾灯灯泡	TAIL LIGHT BULB	FOCO DE CALAVERA	1	B0904
9	331-0055A	B09010003	装饰灯总成	DECORATIVE LIGHT ASSY	FARO AUXILIAR	2	B0901
10	331-0056A	B09040006	牌照灯灯泡	BULB,LICENSE LIGHT	FOCO PORTAPLACA	1	B0904
11	331-0057A	B09040007	灯泡	BULB	FOCO LUZ AUXILIAR	2	B0904
12	331-0043A	B09040008	远光灯泡	HIGH BEAM BULB	FOCO DE FARO	1	B0904
13	331-0059A	B09040009	近光灯泡	BEAM BULB	FOCO LUZ NEUTRAL	1	B0904
14	332-0065A	B09020003	牌照灯总成	LICENSE LIGHT ASSY	CONJUNTO LUZ PORTAPLACA	1	B0902
15	332-0066A	B09050003	后侧光片	REAR REFLECTOR	REFLECTOR TRASERO	2	B0905
16	332-0067A	B09050004	前反光镜	FR.REFLECTOR	REFLECTOR LATERAL DEL.	2	B0905



B10 = 仪表、铜索、锁具和开关 / METER, CABLES, LOCKS & SWITCH / VELOCIMETRO, GUAYAS Y CERRADURAS

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	339-0019A	B10010002	里程表总成	ODOMETER ASSY	CONJUNTO VELOCIMETRO	1	B1001
2	334-0002A	B10010003	转速表总成	TACHOMETER ASSY	TACOMETRO	1	B1001
3	341-0013A	B10050003	左闸把总成	L.HANDLE SWITCH	CONJUNTO DE MANDO IZQUIERDO	1	B1005
4	341-0014A	B10050004	右闸把座总成	R.HANDLE SWITCH	CONJUNTO DE MANDO DERECHO	1	B1005
5	333-0029A	B10030005	里程表软轴	CABLE,ODOMETER	CHICOTE DE VELOCIMETRO	1	B1003
6	270-0080A	B10030006	油门拉索	CABLE,THROTTLE	CHICOTE DE ACELERADOR	1	B1003
7	333-0023A	B06090002	计数器	COUNTER	MEDIDOR DE VELOCIMETRO	1	B0609
8	270-0081A	B10030007	风门拉索	CABLE,CHOKE	CHICOTE DE AHOGADOR	1	B1003
9	270-0082A	B10030008	离合拉索	CABLE,CLUTCH	CHICOTE DE CLUTCH	1	B1003
10	342-0025A	B10020004	套锁	LOCK ASSY	JUEGO COMPLETO DE CERRADURAS (3 Pcs)	1	B1002
11	270-0290A	B10060002	离合线夹	CABLE CLIP	GOMA SUJETADORA DE CHICOTE	1	B1006
12	339-0016A	B10010004	电压表总成	VOTAMETER ASSY	MEDIDOR DE VOLTAJE	1	B1001




B11 = 消声器 / MUFFLER ASSY / ESCAPE

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	481-0032A	B11010003	排气消声器总成	MUFFLER ASSY	CONJUNTO DE ESCAPE	1	B1101
2	481-0033A	B11020001	连接板	CONNECTING PLATE	BASE DE ESCAPE	1	B1102
3	481-0031A	B11030002	护罩	PROTECTOR	CUBIERTA DE ESCAPE	1	B1103
4	481-0034A	B11040002	压板	PRESS PLATE	SUJETADOR DE ESCAPE	1	B1104
5	481-0035A	B11040003	法兰卡子	CLAMP, FLANGE	MEDIA LUNA DE ESCAPE	2	B1104
6	481-0028A	B11040004	消声器密封垫	GASKET, MUFFLER	EMPAQUE DE ESCAPE	1	B1104




B12 = 塑料件和贴花 / PLASTIC COVERS & STICKERS / PLASTICOS Y STICKERS

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	123-0021A	B12010026	右侧盖(黑色)	R.SIDE COVER (BLACK)	CUBIERTA CROMADA DERECHA	1	B1201
1	123-0027A	B12010027	右侧盖 (银色)	R.SIDE COVER(SILVER)	CUBIERTA CROMADA DERECHA	1	B1201
1	123-0028A	B12010028	右侧盖 (钛金色)	R.SIDE COVER(TITANIUM)	CUBIERTA CROMADA DERECHA	1	B1201
2	123-0020A	B12010029	左侧盖 (黑色)	L.SIDE COVER(BLACK)	CUBIERTA CROMADA IZQUIERDA	1	B1201
2	123-0029A	B12010030	左侧盖 (银色)	L.SIDE COVER(SILVER)	CUBIERTA CROMADA IZQUIERDA	1	B1201
2	123-0030A	B12010031	左侧盖 (钛金色)	L.SIDE COVER(TITANIUM)	CUBIERTA CROMADA IZQUIERDA	1	B1201
3	221-0077A	B12010032	油箱装饰罩	DECORATION COVER,FUEL TANK	CUBIERTA SUPERIOR TANQUE GAS.	1	B1201
4	122-0027A	B12010033	右装饰小块	R.SMALL DECORATION COVER	CUBIERTA CROMADA CUADRO DER.	1	B1201
5	131-0034A	B12010034	右装饰条	R.DECORATION	CUBIERTA CROMADA TRASERA DER.	1	B1201
6	122-0028A	B12010035	车头右护板	R.PROTECTION PLATE	BASE CROMADA DE CUBIERTA DER.	1	B1201
7	123-0023A	B12010036	车头左护板	L.PROTECTION PLATE	BASE CROMADA DE CUBIERTA IZQ.	1	B1201
8	122-0029A	B12010037	车头右装饰罩	R.DECORATION COVER	CUBIERTA DECORATIVA CROMADA DER.	1	B1201
9	123-0024A	B12010038	车头左装饰罩	L.DECORATION COVER	CUBIERTA DECORATIVA CROMADA IZQ.	1	B1201
10	123-0033A	B12010039	左装饰条	L.DECORATION	CUBIERTA CROMADA TRASERA IZQ.	1	B1201




B13 = RADIATOR & HOSES / RADIADOR Y MANGUERAS

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	440-0006A	B13020001	油冷器	OIL COOLER	RADIADOR DE ACEITE	1	B1302
2	440-0012A	B13010001	油冷管II	PIPE,OIL COOLER II	MANGUERA LARGA	1	B1301
3	440-0011A	B13010002	油冷管I	PIPE,OIL COOLER I	MANGUER CORTA	1	B1301



B14 = 后摇架 / REAR FORK / HORQUILLA TRASERA

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	213-0030A	B14010002	平叉	SWING ARM	HORQUILLA TRASERA	1	B1401
2	214-0004A	B15090005	链条 428H*132	CHAIN 428H*132	CADENA DE TRACCION 428 x 132	1	B1509
3	262-0060A	B15120001	缓冲胶	CUSHION PAD	DAMPER DE GOMA	4	B1512
4	213-0031A	B15090006	链盒	CHAIN BOX	GUARDA CADENA	1	B1509
5	242-0011A	B14020002	后减震器组件	RR.SHOCK ABSORBER COMP	AMORTIGUADOR TRASERO	2	B1402
6	916-0117A	B14030006	平叉轴	SHAFT,SWING ARM	EJE DE HORQUILLA TRASERA	1	B1403
7	450-0164A	B15100002	缓冲总成	CUSHION ASSY	CONJUNTO DE TRACCION FINAL	1	B1510
8	213-0032A	B14010003	链条护卡	CHAIN GUARD	PROTECTOR DE HORQUILLA	1	B1401
9	970-0060A	B15110003	调节器组件	ADJUST, CHAIN	AJUSTADOR DE CADENA	2	B1511




B15 = 后轮 & 后刹车 / REAR WHEEL & BRAKE ASSY / RUEDA TRASERA Y FRENO TRASERO

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	262-0064A	B15030006	轮圈总成	RIM ASSY	RIN COMPLETO TRAS.	1	B1503
2	262-0065A	B15010003	后轮外胎	TIRE,RR.WHEEL	LLANTA TRAS 130/90-15, 66P	1	B1501
3	262-0066A	B15040002	轴条	SPOKE,RR.WHEEL	RAYO TRAS.	36	B1504
4	252-0119A	B15060004	后制动总成	BRAKE SHOE ASSY	CONJUNTO DE FRENO TRAS.	1	B1506
5	916-0119A	B15050003	后轮轴	SHAFT,RR.WHEEL	EJE DE LA RUEDA TRASERA	1	B1505
6	980-0061A	B15050004	后轮轴右衬套	R.SPACER,RR.WHEEL SHAFT	ESPACIADOR DER. RUEDA TRAS.	1	B1505
7	931-0038A	B15040003	调节螺母	ADJUSTING NUT, SPOKE	TUERCA DE RAYO	72	B1504
8	980-0052A	B15050005	后轮轴左衬套	L.SPACER,RR.WHEEL SHAFT	ESPACIADOR IZQ. RUEDA TRAS.	1	B1505
9	262-0067A	B15020003	后轮内胎	INNER TUBE,RR.WHEEL	CAMARA DE AIRE RUEDA TRASERA	1	B1502
10	931-0003A	B15050006	螺母 M14	NUT M14	TUERCA 14M	1	B1505
11	252-0102A	B15070002	后制动蹄片	RR.BRAKE SHOE	ZAPATA DE FRENO	1	B1507
13	920-0090A	B15050007	垫片	GASKET	SELLO DE ACEITE	1	B1505
14	261-0088A	B06020004	前轮垫带	PROTECTOR,FR.WHEEL	PROTECTOR DE RIN DELANTERO	1	B0602




B16 = 坐垫 & 后货架 / SEAT & RACK / ASIENTOS Y PARRILLAS

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	150-0037A	B16010002	前座垫组件	FR.SEAT COMP	ASIENTO DELANTERO	1	B1601
2	150-0038A	B16010003	后座垫组件	RR.SEAT COMP	ASIENTO TRASERO	1	B1601
3	150-0035A	B16030001	后靠背组件	BACK	CONJUNTO DE RESPALDO	1	B1603
4	970-0075A	B16060001	保险杠	BUMPER	DEFENSA	1	B1606
5	910-0099A	B16070001	U 形螺栓	U-BOLT	TORNILLO EN "U"	1	B1607
6	150-0099A	B16030002	后靠背标贴	UM LOGO	UM LOGO	1	B1603
7	150-0034A	B16030003	右后靠背支架	R.BRACKET, BACK	BASE DERECHA DE RESPALDO	1	B1603
8	150-0033A	B16030004	左后靠背支架	L.BRACKET, BACK	BASE IZQUIERDA DE RESPALDO	1	B1603
9	150-0049A	B16030005	后靠背盖	COVER, BACKREST	CUBIERTA DE RESPALDO	1	B1603



B17 = 方向柱、前减 / STEERING STEM, FRONT SHOCK ABSORBER / SUSPENSION DELANTERA

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	231-0024A	B17010002	上连接板	UPPER CONNECTING PLATE	BASE DE MANUBRIO	1	B1701
2	231-0025A	B17010003	方向柱	STEERING STEM	TELESCOPIO DE DIRECCION	1	B1701
3	241-0039A	B17020002	右前减震器	R.FR.SHORK ABSORBER	AMORTIGUADOR DELANTERO DERECHO	1	B1702
4	241-0040A	B17030002	左前减震器	L.FR.SHORK ABSORBER	AMORTIGUADOR DELANTERO IZQUIERDO	1	B1703
5	960-0045A	B17050001	轴承总成	BEARING ASSY	KIT DE BALEROS DE DIRECCION	1	B1705
6	931-0036A	B17070014	圆螺母 M25*1	NUT M25*1	TUERCA DE AJUSTE	1	B1707
7	916-0116A	B17070015	螺栓 M14*20	BOLT M14*20	TORNILLO DECORATIVO DE DIRECCION	1	B1707
8	980-0055A	B17070016	前减震下左装饰筒	LOWER DECORATION	CARCASA INFERIOR DECORATIVA IZQ	1	B1707
9	980-0056A	B17070017	前减震下右装饰筒	LOWER DECORATION	CARCASA INFERIOR DECORATIVA DER	1	B1707
10	980-0057A	B17070018	减震上装饰筒	UPPER DECORATION	CARCASA SUPERIOR DECORATIVA	2	B1707
11	160-0009A	B17070019	装饰灯支架	BRACKET,HEADLIGHT	BASE DECORATIVA DE FARO	1	B1707
12	970-0068A	B17070020	大灯支架	BRACKET,HEADLIGHT	BASE DE FARO	1	B1707
13	921-0031A	B17070021	前减装饰筒上胶套	UPPER RUBBER SLEEVE,DECORATION	GOMA SUPERIOR DE CARCASA	2	B1707
14	921-0032A	B17070022	前减装饰筒下胶套	LOWER RUBBER SLEEVE,DECORATION	GOMA INFERIOR DE CARCASA	2	B1707
15	970-0072A	B17070023	右侧反光器支架	BRACKET,R.REFLECTOR	BASE DERECHA REFLEJANTE	1	B1707
16	970-0070A	B17070024	左转向灯支架	BRACKET,L.TURNSIGNAL LIGHT	BASE IZQUIERDA DIRECCIONAL	1	B1707
17	970-0071A	B17070025	右转向灯支架	BRACKET,R.TURNSIGNAL LIGHT	BASE DERECHA DIRECCIONAL	1	B1707
18	970-0069A	B17070026	左侧反光器支架	BRACKET,L.REFLECTOR	BASE IZQUIERDA REFLEJANTE	1	B1707
19	150-0099A	B16030002	前叉标牌	UM LOGO	LOGO UM	1	B1707




F01 = 进气和排气系统 / AIR INLET EXHAUST SYSTEM / TREN DE VALVULAS

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	410-0012A	E01050001	进气门	INLET VALVE	VALVULA DE ADMISION	1	E0105
2	410-0013A	E01050002	排气门	EXHAUST VALVE	VALVULA DE ESCAPE	1	E0105
3	410-0005A	E01020001	挡油罩组合	ASSEMBLY, VALVE STEM SEAL	SELLO DE VALVULA	2	E0102
4	410-0014A	E01040001	气门外弹簧座圈(下)	RETAINER, VALVE OUTER SPRING	ASIENTO DE RESORTE EXTERNO DE	2	E0104
5	940-0001A	E01040002	气门外弹簧	VALVE OUTER SPRING	RESORTE EXTERNO DE VALVULAS	2	E0104
6	940-0002A	E01040003	气门内弹簧	VALVE INNER SPRING	RESORTE INTERNO DE VALVULAS	2	E0104
7	410-0016A	E01040004	气门弹簧座(上)	RETAINER, VALVE SPRING	RETEN DE RESORTE DE VALVULAS	2	E0104
8	410-0017A	E01050003	气门锁夹	VALVE COTTER	SEGÜROS DE VALVULA	4	E0105
9	410-0020A	E01010001	气门摇臂组合	ASSEMBLY, VALVE ROCKER ARM	CONJUNTO BALANCIN	1	E0101
10	410-0024A	E01040005	下摇臂	LOWER ROCKER ARM	BRAZO IMPULSOR DE VALVULAS	2	E0104
12	410-0025A	E01040007	下摇臂轴	SHAFT, LOWER ROCKER ARM	EJE DE BRAZO IMPULSOR	1	E0104
13	921-0004A	E01020002	O形密封圈 20×2.5	O-RING 20×2.5	O-RING 20×2.5	1	E0102
14	921-0003A	E01020003	O形密封圈 18×2.5	O-RING 18×2.5	O-RING 18 X 2.5	1	E0102
15	940-0003A	E01040008	配气凸轮轴弹簧	SPRING, VALVE CAMSHAFT	RESORTE	1	E0104
16	410-0023A	E01030001	正时从动齿部件	ASSEMBLY, TIMING DRIVEN GEAR	ENGRANE IMPULSOR	1	E0103
17	410-0022A	E01040009	推杆组合	ASSEMBLY, PUSH ROD	VARILLA IMPULSORA	2	E0104
18	410-0015A	E01040010	气门内弹簧座圈(下)	RETAINER, VALVE INNER SPRING	ASIENTO DE RESORTE INTERNO DE	2	E0104
19	410-0010A	E01060003	气门间隙调节螺钉	ADJUSTING SCREW, VALVE CLEARANCE	TORNILLO DE AJUSTE DE VALVULA	2	E0106
20	410-0018A	E01060004	气门间隙调节螺母	ADJUSTING NUT, VALVE CLEARANCE	TUERCA DE AJUSTE DE VALVULA	2	E0106
21	910-0005A	E01060001	上摇臂螺栓 M8×33	BOLT M8×33	TORNILLO	3	E0106
22	410-0026A	E01060002	配气凸轮轴	CAMSHAFT, VALVE	EJE DE ENGRANE IMPULSOR	1	E0104




E02 - 化油器 and 发动机 / CARBURETOR AND ENGINE / CARBURADOR Y MOTOR							
ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	470-0135A	E02010002	CG200-A化油器(PZ30 不带加速泵 手动)	COMPONENT, CARBURETOR (PZ27)	CARBURADOR	1	E0201




F03 - 离合器 / CLUTCH / EMBRAGUE

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	450-0009A	E03020001	离合器外罩组合	CLUTCH OUTER CASE COMP	TAMBOR DE CLUTCH	1	E0302
2	450-0007A	E03030001	离合器压盘	CLUTCH PRESSING PLATE	PLATO OPRESOR	1	E0303
3	450-0006A	E03030002	离合器从动摩擦片	FRICTION PLATE ASSY	DISCOS DE TRACCION	5	E0303
4	450-0005A	E03030003	离合器主动摩擦片	FRICTION PLATE ASSY	DISCOS DE FRICCION	6	E0303
5	450-0594A	E03010002	离合器端盖组合	END COVER,CLUTCH	CUBIERTA FINAL DE CLUTCH	1	E0301
6	450-0595A	E03020003	离合器中心套	CENTRAL SLEEVE,CLUTCH	COMPUESTO PRIMARIO DE CLUTCH	1	E0302
7	960-0002A	E03050001	轴承 (16003)	BEARING (6001)	BALERO 6001	1	E0305
8	910-0010A	E04060006	法兰盘螺栓M6 X 20(白锌)	BOLT M6 X 20	TORNILLO M6 X 20	6	E0306
9	940-0005A	E03060001	离合器弹簧	SPRING,CLUTCH	RESORTE	6	E0306
10	450-0008A	E03060002	离合器花键垫圈	SPLINE WASHER	RONDANA	1	E0306
11	450-0002A	E03060003	离合器推杆	PUSH ROD,CLUTCH	VARILLA DE EMPUJE, EMBRAGUE	1	E0306
12	451-0034A	E03020004	CG200-A水冷-2#离合器总成	CLUTCH COMP	CONJUNTO EMBRAGUE	1	E0302




F04 - 曲轴箱 / CRANKCASE ASSEMBLY / CARCAZAS DE MOTOR (CARTER)

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	434-0035A	E04010002	右曲轴箱组合	ASSEMBLY, RIGHT CRANKCASE	CARTER MOTOR IZQUIERDA	1	E0401
2	434-0029A	E04050001	气门室盖	CAP, TAPPET ADJUSTING HOLE	TAPON DE AJUSTE DE FUNTERIAS	1	E0405
3	921-0007A	E04020001	O形密封圈 35×3	O-RING 35×3	O-RING 35 X 3	1	E0402
4	940-0007A	E04050002	机油过滤网弹簧	SPRING, OIL FILTER SCREEN	RESORTE	1	E0405
5	434-0030A	E04050003	机油过滤网组合	ASSEMBLY, OIL FILTER SCREEN	PANTALLA FILTRANTE DE ACEITE	1	E0405
6	434-0031A	E04020002	换档臂油封 14×28×7	OIL SEAL 14×28×7	SELLO DE ACEITE 14 x 28 x 7	1	E0402
7	434-0034A	E04020003	曲轴油封 34×50×7	OIL SEAL 34×50×7	SELLO DE ACEITE	1	E0402
8	434-0344A	E04060013	定位销 10×14	DOWEL PIN 10×14	CUPILLA	3	E0406
9	910-0003A	E07040004	螺栓 M6×25	BOLT M6×25	TORNILLO M6 X 25	1	E0406
10	434-0019A	E04060002	离合器钢索支架	STEEL BRACKET, CLUTCH	RUTEADOR DE CABLE DE CLUTCH	1	E0406
11	434-0033A	E04050004	压指体组合	ASSEMBLY, PRESSURE PIN	OPRESOR DE ACEITE	1	E0405
12	450-0185A	E04050006	档号线束组合	CABLE ASSEMBLY, GEAR INDICATION	SENSOR DE CAMBIOS	1	E0405
13	450-0018A	E04020007	脚踏油封 20×34×7	OIL SEAL 20×34×7	SELLO DE ACEITE	1	E0402
14	960-0023A	E04030001	滚针轴承 (NK152312)	NEEDLE BEARING (NK152312)	BALERO RADIAL HK 101410	1	E0403
15	434-0023A	E04020005	CG125D-1#通气管	SEPARATOR, FUEL 1 AND AIR	MANGUERA RESPIRADERO	1	E0402
16	434-0021A	E04060004	气缸头AB栓螺母 M8×32	NUT M8×32	TUERCA M8×32	4	E0406
17	434-0110A	E04060014	CG125D-3#气缸双头螺栓B(螺纹22mm 杆径7.5)	STUD B	BIRLO DE CILINDRO	1	E0406
18	434-0024A	E04060003	CG200D-B-3#气缸双头螺栓B(螺纹22mm 杆径7.5)	STUD B	BIRLO DE CILINDRO	2	E0406
19	434-0027A	E04010001	左曲轴箱组合	ASSEMBLY, LEFT CRANKCASE	CARTER MOTOR DERECHA	1	E0401
20	434-0026A	E04020006	曲轴箱密封垫	GASKET, CRANKCASE	EMPAQUE DE CARTER	1	E0402
21	910-0001A	E08030001	螺栓 M6×28	BOLT M6×28	TORNILLO M6 X 28	2	E0406
22	920-0091A	E04060015	铝垫圈 12.5×1.5×20	WASHER 12.5×1.5×20 (ALUMINIUM)	ARANDELA	1	E0406
23	434-0124A	E04060016	放油螺塞 M12×1.5	OIL DRAIN PLUG M12×1.5	TAPON DE DRENADO	1	E0406




E05 - 曲轴 & 活塞 / CRANKSHAFT & PISTON / CIGÜEÑAL, PISTON Y ANILLOS

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	433-0001A	E05020001	曲轴连杆部件	ASSEMBLY, CONNECTING ROD CRANKSHAFT	CIGÜEÑAL	1	E0502
2	420-0052A	E05010005	活塞环总成	ASSEMBLY, PISTON RING	JUEGO DE ANILLOS	1	E0501
3	420-0003A	E05010002	活塞	PISTON	PISTON	1	E0501
4	420-0004A	E05010003	活塞销	PISTON PIN	PASADOR DE PISTON	1	E0501
5	951-0002A	E05010004	活塞销挡圈	CIRCLIP, PISTON PIN	SEGURO DE PASADOR	2	E0501
6	433-0003A	E05030001	半圆键 25×14×4	SEMICIRCULAR KEY 25×14×4	PRISIONERO	2	E0503
7	433-0007A	E05030002	平衡从动齿轮组合	DRIVEN GEAR ASSEMBLY, BALANCE	ENGRANE IMPULSOR DE BALANCEADO	1	E0503
8	960-0016A	E05030010	轴承 (6203)	BEARING (6203)	BALERO 6203	1	E0503
9	433-0008A	E05030004	平衡轴	BALANCE SHAFT	BALANCEADOR	1	E0503
10	960-0005A	E05030005	轴承 (6303)	BEARING (6303)	BALERO 6303	1	E0503
11	450-0186A	E05030011	机油泵主动齿轮	DRIVE SPROCKET, OIL PUMP	ENGRANE IMPULSOR DE BOMBA DE ACEITE	1	E0503
12	433-0006A	E05030008	主动齿轮	DRIVE GEAR	ENGRANE REDUCTOR DE CIGÜEÑAL	1	E0503
13	433-0004A	E05030007	平衡主动齿轮	DRIVING GEAR, BALANCE	ENGRANE RECEPTOR DE BALANCEADO	1	E0503
14	910-0013A	E05030009	螺栓安装螺栓 M10×36	BOLT M10×36	TORNILLO DE FIJACION TIEMPO	1	E0503
15	433-0002A	E05030012	曲轴正时主动齿轮	TIMING DRIVE GEAR, CRANKSHAFT	ENGRANE DE TIEMPO DE CIGÜEÑAL	1	E0503
16	960-0236A	E05030013	轴承 (63/28/P5)	BEARING (63/28/P5)	BALERO (63/28/P5)	1	E0503




E06 - 汽缸体 / CYLINDER BLOCK / CILINDRO DE MOTOR

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	420-0113A	E06010002	汽缸体部件	ASSEMBLY, CYLINDER BLOCK	CILINDRO	1	E0601
2	420-0001A	E06020001	汽缸体密封垫	GASKET, CYLINDER BLOCK	JUNTA DE CILINDRO	1	E0602
3	410-0010A	E06020002	汽缸头密封垫组合	GASKET ASSEMBLY, CYLINDER HEAD	EMPAQUE DE CABEZA DE CILINDRO	1	E0602
4	410-0011A	E06030001	定位销 10*20	DOWEL PIN 10*20	PASADOR DE SUJECION 10*20	3	E0603
5	910-0410A	E06030002	缸体箱体连接螺栓 M6*22	BOLT M6*22	TORNILLO 6M X 22	2	E0603




E07 = 汽缸头和盖 / CYLINDER HEAD & COVERS / CULATA Y CUBIERTAS

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	410-0001A	E07010001	汽缸头上盖	UPPER COVER, CYLINDER HEAD	CUBIERTA DE CABEZA DE CILINDRO	1	E0701
2	410-0002A	E07030001	汽缸头上盖密封圈	GASKET,CYLINDER HEAD UPPER COVER	EMPAQUE CUBIERTA DE VALVULAS	1	E0703
3	920-0001A	E07040001	缸垫圈6.5×1.5×12	WASHER 6.5×1.5×12	RONDANA	1	E0704
4	910-0002A	E13010002	螺栓 M6×12	BOLT M6×12	TORNILLO M6 X 12	1	E0704
5	930-0001A	E07040002	螺母 M6	NUT M6	TUERCA	2	E0704
6	410-0313A	E07010003	汽缸头组合	ASSEMBLY, CYLINDER HEAD	CONJUNTO CABEZA DE CILINDRO	1	E0701
7	410-0006A	E07020001	火花塞部件	SPARK PLUG (D8TC)	BUJIA (D8TC)	1	E0702
8	910-0004A	E07040003	缸头缸体连接螺栓 M8×82	BOLT M8×82	TORNILLO M8×82	1	E0704
9	410-0003B	E07050002	缸头缸体连接螺栓 M8×82	ASSEMBLY, INLET PIPE (IQ-18)	PIPE TA	1	E0705
10	910-0251A	E07040007	螺栓 M6×20	BOLT M6×20	TORNILLO M6×20	2	E0704
11	921-0001A	E07030002	O形密封圈 33.5×3	O-RING 33.5×3	O-RING 33.5×3	1	E0703




F08 - 齿轮 / GEAR SHIFTING / TAMBOR SELECTOR

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	450-0574A	E08010009	换挡臂部件	ASSEMBLY, GEARSHIFT LEVER	SELECTOR DE CAMBIOS COMPLETO	1	E0801
2	450-0040A	E08010003	拨叉轴	SHAFT, FORK SPREADER	EJE DEL TAMBOR SELECTOR	1	E0801
3	450-0041A	E08010004	副轴右拨叉	RIGHT FORK SPREADER,COUNTERSHAFT	HORQUILLA DE CAMBIOS	1	E0801
4	450-0042A	E08010005	主轴拨叉	FORK SPREADER, MAINSHAFT	HORQUILLA DE CAMBIOS	1	E0801
5	450-0043A	E08010006	副轴左拨叉	LEFT FORK SPREADER, COUNTERSHAFT	HORQUILLA DE CAMBIOS	1	E0801
6	910-0003A	E07040004	螺栓 M6×25	BOLT M6×25	TORNILLO M6 X 25	1	E0406
7	450-0044A	E08010007	五星板	STOPPING PLATE	FIADOR DE TAMBOR	1	E0801
8	450-0045A	E08040001	销子 4×10	PIN 4×10	PIN POSICIONADOR	1	E0804
9	450-0046A	E08010008	变速鼓	GEARSHIFT DRUM	TAMBOR SELECTOR DE CAMBIOS	1	E0801
10	940-0013A	E07040005	定位板弹簧	SPRING, LOCATING PLATE	RESORTE	1	E0804
11	450-0047A	E08040002	定位板组合	ASSEMBLY, LOCATING PLATE	INDICADOR DE LUZ NEUTRAL	1	E0803
12	910-0003A	E07040004	螺栓 M6×20	BOLT M6×20	TORNILLO M6×20	1	E0704




F09 - 左曲轴箱 / LEFT CRANKCASE COVER / CUBIERTA IZQUIERDA DE MOTOR

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	434-0013A	E09010001	左曲轴箱前盖 (鲑鱼款)	FRONT COVER, LEFT CRANKCASE	CUBIERTA IZQUIERDA DE CARTER	1	E0901
2	434-0018A	E09010002	左曲轴箱后盖 (鲑鱼款)	REAR PART, LEFT CRANKCASE COVER	CUB. TRAS. IZQUIERDA	1	E0901
3	434-0017A	E09010003	双联齿轮盖	COVER, DOUBLE GEAR	CUBIERTA ENGRANE DE REDUCCIÓN	1	E0901
4	910-0009A	E09050003	小盘螺栓 M8×50	BOLT M8×50	TORNILLO M8×50	2	E0905
5	434-0015A	E12010002	左曲轴箱前盖装饰盖 (鲑鱼款)	DECORATE COVER, FRONT COVER	CUBIERTA DECORATIVA IZQUIERDA	1	E0901
6	910-0002A	E13010002	螺钉 M6×12	BOLT M6×12	TORNILLO 6M X 12	4	E0704
7	434-0012A	E09030001	左曲轴箱前盖密封垫	GASKET, FRONT COVER, LEFT CRANKCASE	EMPAQUE CUBIERTA IZQUIERDA DE CARTER	1	E0903
8	910-0007A	E09050001	小盘螺栓 M6×40	BOLT M6×40	TORNILLO M6 X40	5	E0905
9	434-0014A	E12030005	定位销 10×14	DOWEL PIN 10×14	PIN PASADOR 10×14	2	E0406
10	434-0016A	E09030002	O形密封圈 62×3	O-RING 62×3	SELLO DE ACEITE 62 X 3	1	E0903




E10 = 磁电机 / MAGNETO / GENERADOR

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	311-0057A	E10010003	磁电机	MAGNETO	GENERADOR	1	E1001
2	432-0001A	E10020001	磁电机转子组合	ROTOR ASSEMBLY, MAGNETO	ROTOR	1	E1002
3	311-0002A	E10010002	磁电机定子组合	STATOR ASSEMBLY, MAGNETO	ESTATOR	1	E1001




E11 = 油泵 & 汽滤过滤器 / OIL PUMP&OIL FILTER COMP / BOMBA DE ACEITE Y FILTROS

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	461-0001A	E11020001	机油滤清器部件	ASSEMBLY, OIL FILTER	FILTRO DE ACEITE	1	E1102
2	460-0001A	E11040001	机油泵链条	CHAIN, OIL PUMP	CADENA DE BOMBA DE ACEITE	1	E1104
3	460-0003A	E11010001	机油泵部件	OIL PUMP	BOMBA DE ACEITE	1	E1101




F12 = 右箱体 / RIGHT CRANKCASE COVER / CUBIERTA DERECHA DE MOTOR

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	434-0003A	E12010001	右曲轴箱盖组合 (标准款)	ASSEMBLY, RIGHT CRANKCASE COVER	CUBIERTA DERECHA DE CARTER	1	E1201
2	434-0001A	E12020001	离合器操纵臂组合	CONTROLLING ARM ASSEMBLY,CLUTCH	ACTUADOR DE EMBRAGUE	1	E1202
3	434-0004A	E12050001	机油尺组合	DIPSTICK	MEDIDOR NIVEL DE ACEITE	1	E1205
4	434-0006A	E12030001	右曲轴箱盖密封垫	GASKET, RIGHT CRANKCASE COVER	EMPAQUE CUBIERTA DERECHA DE CA	1	E1203
5	434-0009A	E12010003	右曲轴箱盖装饰盖 (铁汉款)	DECORATE COVER, RIGHT CRANKCASE COVER	TAPA DECORATIVA DE CLUTCH	1	E1201
6	910-0007A	E09050001	小直径螺栓 M8×40	BOLT M8×40	TORNILLO M8×40	11	E0905
7	434-0007A	E12050002	机油观察窗	WINDOW, OIL LEVEL	MIRILLA DE ACEITE	1	E1205
8	434-0008A	E12030002	启动轴油封 16×28×7	OIL SEAL 16×28×7	SELLO DE ACEITE 16×28×7	1	E1203



E13 = 启动马达 / STARTING MOTOR / ARRANQUE DE MOTOR

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	320-0062A	E13010003	3#启动电机部件	ASSEMBLY, STARTING MOTOR	MOTOR DE ARRANQUE	1	E1301
2	431-0001A	E13010004	CG125D-2#双联齿轮轴	SHAFT, DOUBLE GEAR	EJE DE IMPULSOR DE ARRANQUE	1	E1301
3	431-0006A	E13020006	启动离合滚柱	ROLLER, STARTING CLUTCH	RODAMIENTO	3	E1302
4	920-0010A	E13030001	双联齿轮垫圈 10.5*0.5*18	WASHER 10.5*0.5*18	RONDANA	4	E1303
5	431-0003A	E13020002	CG125D-2# 双联齿轮组合(一)带含油轴承	DOUBLE GEAR 1	ENGRANE DUAL 1	1	E1302
6	431-0004A	E13020003	CG125D-4# 双联齿轮组合(二)含油轴承专用	DOUBLE GEAR 2	PIÑÓN PEQUEÑO DE ARRANQUE	1	E1302
7	431-0056A	E13020007	启动离合器总成	ASSEMBLY, STARTING CLUTCH	EMBRAGUE DE ARRANQUE	1	E1302
8	431-0009A	E13020005	启动大链轮	STARTING MOTORDRIVEN SPROCKET	ENGRANE IMPULSOR DE ARRANQUE	1	E1302
9	434-0037A	E13030002	齿轮定位板	LOCATING PLATE, GEAR	PLACA	1	E1303
10	910-0002A	E13010002	螺栓 M6*12	BOLT M6*12	TORNILLO M6 X 12	2	E0704



E14 - 传动系统 / TRANSMISSION / TRANSMISION

ITEM	OLD Part #	UM Part #	Chinese	Description	Spanish	Quantity	SECTION
1	450-0183A	E14020002	CG125D启动轴总成(油封光杆L:60)	KICK STARTING SHAFT ASSEMBLY	EJE DE ARRANQUE COMPLETO	1	E1402
2	920-0007A	E14020003	CG200D-B副轴组合(157 链轮升移)	COUNTERSHAFT TRANSMISSION	EJE CONDUCTOR COMPLETO	1	E1402
3	450-0035A	E14020004	CG200D-B主轴组合	MAIN SHAFT, TRANSMISSION	EJE PRIMARIO COMPLETO	1	E1402
4	450-0028A	E14010001	主动链轮	DRIVE SPROCKET	PIÑON DELANTERO	1	E1401
5	450-0050A	E14040001	CB125脚主动链轮固定板	FIXING PLATE,DRIVE SPROCKET	PLACA FIJA	1	E1404